



# **STYCCOBOND B95**

High Performance, Flexible Wood Flooring Adhesive

# PRODUCT DATA

# INTRODUCTION

STYCCOBOND B95 is a high performance, one part, flexible, moisture curing polyurethane adhesive used for installing a wide range of wood floorcoverings. It is non-flammable and is quick setting to develop a high bond strength. It is protected against bio-degradation and suitable for use over normal underfloor heating.

STYCCOBOND B95 can be used for securing engineered boards (semi-solids) and a wide range of plank and wood strip flooring up to a maximum length of 1.5 metres.

STYCCOBOND B95 can be applied to STOPGAP smoothing underlayments, structurally sound, smooth, dry subfloors of concrete, sand/cement screed and plywood (Minimum 6mm flooring grade WBP).

Sound asphalt and other non-absorbent surfaces must be skimmed with a minimum of 3mm of the appropriate STOPGAP smoothing underlayment.

STYCCOBOND B95 can also be applied directly to STOPGAP waterproof surface membranes within 24 hours of the membrane curing.

# SURFACE PREPARATION

Proper subfloor preparation is essential for the correct installation of any floorcovering. Subfloors must be structurally sound, smooth, dry (<65% RH) and free from laitance and any contaminants which will affect adhesion. Use STYCCOCLEAN C140 for removing grease, oil, polish, soap etc. from non-absorbent substrates.

Concrete and sand/cement screeds must be fully cured and any laitance or surface treatments must be removed. The temperature of the floor must be maintained above  $10^{\circ}$ C throughout the application and drying of the adhesive. Underfloor heating must be off for at least 48 hours before, during and after application.

For detailed information, request our Subfloor Preparation Guide.

# DAMP SUBFLOORS

Prior to the installation of a wood floorcovering the Relative Humidity of the subfloor should be checked using a Hygrometer. F. Ball would always recommend a RH value of 65% or less, however the wood flooring manufacturer should also be consulted.

# **TECHNICAL INFORMATION**

Colour	Beige
Installation Conditions	Ambient temperature must be above 15°C
Coverage Rates (approx.) Sausage	800g/m <sup>2</sup> with a B3 or 3mm x 6mm trowel or 1000g/m <sup>2</sup> with a B11 trowel 1.0m <sup>2</sup> - 2.0m <sup>2</sup> applied at 125 - 250mm centres
Open Time	Up to 20 minutes depending on temperature, humidity and absorbency of the subfloor



#### **FEATURES**

- Flexible with high bond strength
- Quick setting
- Isocyanate and solvent free
- Suitable for a wide range of wood floorcoverings
- Can be applied directly to STOPGAP Waterproof Surface Membranes

# **STANDARDS**

All aspects of the installation of floorcoverings should be in accordance with the requirements of the relevant British Standard Code of Practice i.e. BS 8201 (The code of practice for flooring of timber, timber products and wood based panel products) and supplementary specifications.

# PACKAGING

8kg plastic bucket 15kg plastic bucket 1kg foil / sausage - 15 per carton

## **HOW MUCH MATERIAL?**

TROWEL NOTCH SIZE	COVERAGE PER UNIT
B3 3mm x 6mm	10 m <sup>2</sup>
BII	8 m²
B3 3mm x 6mm	18,75 m <sup>2</sup>
BH	15 m <sup>2</sup>
	B3 3mm x 6mm B11 B3 3mm x 6mm

Note: Coverage rates will depend on the condition and absorbency of the subfloor.



Where necessary, treat with the appropriate  $\ensuremath{\mathsf{STOPGAP}}$  Waterproof Surface Membrane.

# SMOOTHING

To ensure a level surface on which to adhere to, uneven and irregular surfaces should be suitably prepared using STOPGAP smoothing underlayments. F. Ball recommends the use of STOPGAP 200 *SMOOTH* or STOPGAP 300 *HD* for this purpose due to their high performance characteristics. Application should be in accordance with instructions on the appropriate Technical Data Sheet.

# PRIMING

Priming is not required.

# **ADHESIVE APPLICATION**

Holding the trowel at an angle of  $60^\circ$ , spread the adhesive evenly over an area of subfloor that can be covered whilst the adhesive remains receptive and gives good transfer. Place the wood flooring in position and press firmly over the whole surface to ensure good transfer.

Longer lengths of wood flooring may require weighting or clamping to ensure permanent contact whilst the adhesive is setting.

## Beaded (Baton) Application Using the Sausage

This adhesive application method is generally suitable for areas up to  $20 \text{ m}^2$  and for use with random length wood flooring between 18 - 28 mm in thickness and with a width between 50 - 120 mm, providing a minimum 3 adhesive beads are in contact with the each length of flooring.

Place the sausage into the applicator gun and cut the end off the foil. Replace the cap and cut the plastic nozzle to provide a bead of approximately 10mm.

To a smooth dry absorbent base gun out a bead of Styccobond B95 at 125 - 250 mm centres depending on the type of timber flooring being fitted. Only gun out sufficient length of bead to enable placement of the wood flooring without the adhesive skinning and curing, any remaining cured adhesive must be scraped away. Place the wood flooring at right angles to the adhesive bead ensuring any unsupported ends receive an additional adhesive bead, then press the wood into place ensuring that a good overall adhesive contact is maintained whilst the adhesive cures.

Coverage rates - A 1kg sausage will cover between  $1.0 - 2.0 \text{ m}^2$  when applied between 125 - 250mm centres and depending upon the surface profile.

This application method is not suitable when using particularly sensitive floor coverings such as bamboo or those with a high oil content.

Before installing the timber flooring, reference should be made to the flooring manufacturers conditioning and fitting instructions.

The open time of the adhesive is dependent on temperature, humidity and absorbency of the subfloor.

# **CURE TIME**

STYCCOBOND B95 is moisture curing and cure time is dependent on the moisture contained within the base and timber. Generally finishing operations can be commenced after 16 hours on absorbent bases, but up to 3 days on surfaces with little or no absorbency.

# PRECAUTIONS

Do not commence finishing operations until the adhesive has set – typically 16 hours on absorbent bases - this will be extended for lower temperatures and non-absorbent subfloors. Ensure that no adhesive residue is present on the surface of the wood flooring. Remove excess adhesive from floorcovering before it has cured with a dry, clean cloth.

Ensure the timber flooring is acclimatised prior to installation.

Please refer to F. Ball Technical Service Department for specific guidance in the case of pre-treated types of wood and those with high oil contents.

# TOOLS

STYCCOBOND 3mm x 6mm or a B3 or a B11 'V' notched trowel. Applicator gun for 1kg sausage.

Tools should be cleaned with F. Ball STYCCOWIPES immediately after use.

## **STORAGE**

Store between  $5^\circ\text{C}$  and  $30^\circ\text{C}$  and protect from frost.

# SHELF LIFE

9 months in unopened buckets and stored under good conditions.24 months in foil sausage.

## HEALTH AND SAFETY ADVICE

This product is not classified. Obtain the relevant Safety Data Sheet and follow the advice given. These can be found at www.f-ball.co.uk or alternatively obtained from the point of purchase or from F. Ball and Co. Ltd at the address below.

Site conditions vary, to ensure this product is suitable and to confirm this data sheet is current please contact our Technical Service Department.



For further information about F. Ball products or more detailed technical assistance, please contact:



Churnetside Business Park Station Road, Cheddleton, Leek Staffordshire ST13 7RS United Kingdom

Tel: +44 (0) 1538 361633 Fax: +44 (0) 1538 361622 Tech Services Fax: +44 (0) 1538 361567 Email: mail@f-ball.co.uk

www.f-ball.co.uk

