



# STYCCOBOND B95

## High Performance, Elastic Wood Flooring Adhesive

### INTRODUCTION

STYCCOBOND B95 is a high performance, elastic, SMP-based wood flooring adhesive used for installing a wide range of engineered boards (semi-solids) and a wide range of solid plank and wood strip flooring. It is quick setting to develop a high bond strength and is both isocyanate and solvent-free.

STYCCOBOND B95 can be applied to STOPGAP smoothing compounds, structurally sound, smooth, dry subfloors of concrete and sand/cement screed, calcium sulphate screeds, plywood and hardboard.

STYCCOBOND B95 can also be applied directly to STOPGAP epoxy waterproof surface membranes within 24 hours of the membrane curing. Sound flooring grade asphalt and some non-absorbent surfaces must be skimmed with a minimum of 3mm of the appropriate STOPGAP smoothing compound.

STYCCOBOND B95 is suitable for use over normal underfloor heating installations. For details on other subfloors, contact our Technical Service Department.

### TECHNICAL INFORMATION

Colour	Beige
Consistency	Paste
Installation Conditions	Ambient temperature must be above 15°C
Coverage rates (Approx.)	Up to 800g/m <sup>2</sup> with a B3 or STYCCOBOND 3mm x 6mm 'V' notched trowel Up to 1000g/m <sup>2</sup> with a B11 'V' notched trowel
Sausage	1.0m <sup>2</sup> - 2.0m <sup>2</sup> applied at 125 - 250mm centres
Open time	Up to 20 minutes depending on temperature, humidity and absorbency of the subfloor
Shore A Hardness	44
Shear Strength	≥ 1.0 N/mm <sup>2</sup>
Shear Elongation	≥ 2.0

### COVERAGE

PACK SIZE	TROWEL SIZE	COVERAGE PER UNIT
8kg	B3, 3mm x 6mm	10m <sup>2</sup>
8kg	B11	8m <sup>2</sup>
15kg	B3, 3mm x 6mm	18.75m <sup>2</sup>
15kg	B11	15m <sup>2</sup>

Coverage rates will depend on the condition and absorbency of the subfloor

### FEATURES

- Elastic with high bond strength
- Quick setting
- Suitable with underfloor heating
- Isocyanate and solvent free
- Suitable for a wide range of wood floorcoverings
- Can be applied directly to STOPGAP Epoxy Waterproof Surface Membranes

### STANDARDS

All aspects of the installation of floorcoverings should be in accordance with the requirements of the relevant British Standard Code of Practice i.e. BS 8201 (The code of practice for installation of flooring of wood and wood-based panels) and supplementary specifications.

SCAN QR CODE TO VIEW PRODUCT DEMO VIDEO



## SURFACE PREPARATION

Proper subfloor preparation is essential for the correct installation of any floorcovering. Subfloors must be structurally sound, smooth, dry (<65% RH) and free from laitance and any contaminants which will affect adhesion. Use STYCCOCLEAN C140 for removing grease, oil, polish, soap etc. from non-absorbent substrates.

Concrete and sand/cement screeds must be fully cured and any laitance or surface treatments must be removed. The temperature of the floor must be maintained above 10°C throughout the application and drying of the adhesive. Underfloor heating must be off for at least 48 hours before, during and after application.

For detailed information, request the **F. Ball Subfloor Preparation Guide**.

## DAMP SUBFLOORS

Prior to the installation of a wood floorcovering the Relative Humidity of the subfloor should be checked using a Digital Hygrometer. F. Ball would always recommend a RH value of 65% or less, however the wood flooring manufacturer should also be consulted.

Where necessary, treat with the appropriate STOPGAP waterproof surface membrane

## SMOOTHING

To ensure a level surface on which to adhere to, uneven and irregular surfaces should be suitably prepared using STOPGAP smoothing compounds. F. Ball recommends the use of STOPGAP 300 or STOPGAP 700 due to their high performance characteristics. Application should be in accordance with instructions on the appropriate Technical Data Sheet.

## PRIMING

Priming is not required.

## ADHESIVE APPLICATION

Holding the trowel at an angle of 60°, spread the adhesive evenly over an area of subfloor that can be covered whilst the adhesive remains receptive and gives good transfer. Place the wood flooring in position and press firmly over the whole surface to ensure good transfer.

Longer lengths of wood flooring may require weighting or clamping to ensure permanent contact whilst the adhesive is setting.

**FOR FURTHER INFORMATION ABOUT F. BALL PRODUCTS OR MORE DETAILED TECHNICAL ASSISTANCE, VISIT F-BALL.COM OR CALL +44 (0)1538 361633**

## Beaded (Baton) Application Using the Sausage

This adhesive application method is generally suitable for areas up to 20m<sup>2</sup> and for use with random length wood flooring between 18 - 28mm in thickness and with a width between 50 - 120mm, providing a minimum 3 adhesive beads are in contact with the each length of flooring.

Place the sausage into the applicator gun and cut the end off the foil. Replace the cap and cut the plastic nozzle to provide a bead of approximately 10mm.

To a smooth dry absorbent base, gun out a bead of STYCCOBOND B95 at 125 - 250mm centres depending on the type of timber flooring being fitted. Only gun out sufficient length of bead to enable placement of the wood flooring without the adhesive skinning and curing, any remaining cured adhesive must be scraped away. Place the wood flooring at right angles to the adhesive bead ensuring any unsupported ends receive an additional adhesive bead, then press the wood into place ensuring that a good overall adhesive contact is maintained whilst the adhesive cures.

This application method is not suitable when using particularly sensitive floorcoverings such as bamboo or those with a high oil content.

Before installing the timber flooring, reference should be made to the flooring manufacturers conditioning and fitting instructions.

The open time of the adhesive is dependent on temperature, humidity and absorbency of the subfloor.

## CURE TIME

STYCCOBOND B95 is moisture curing and cure time is dependent on the moisture contained within the base and timber. Generally finishing operations can be commenced after 16 hours on absorbent bases, but up to 3 days on surfaces with little or no absorbency.

## PRECAUTIONS

Do not commence finishing operations until the adhesive has set – typically 16 hours on absorbent bases – this will be extended for lower temperatures and non-absorbent subfloors. Ensure that no adhesive residue is present on the surface of the wood flooring. Remove excess adhesive from floorcovering before it has cured with a dry, clean cloth.

Ensure the timber flooring is acclimatised prior to installation and remains in full contact with the adhesive film while it cures.

Please refer to F. Ball Technical Service Department for specific guidance in the case of pre-treated types of wood and those with high oil contents.



## TOOLS

- STYCCOBOND 3mm x 6mm or a B3 or a B11 'V' notched trowel
- Applicator gun for 1kg sausage
- Tools should be cleaned with F. Ball STYCCO-WIPES immediately after use

## STORAGE

Store between 5°C and 30°C. Protect from frost.

## PACK SIZE

8kg bucket  
15kg bucket  
1kg foil/sausage - 15 per carton

## SHELF LIFE

12 months in unopened containers stored under good conditions.  
24 months in foil sausage.

## HEALTH & SAFETY

This product is not classified. Relevant safety data sheets and advice given can be found at [www.f-ball.com](http://www.f-ball.com).

Alternatively these can be obtained from the point of purchase or from F. Ball and Co. Ltd. at the address below.

Site conditions vary, to ensure this product is suitable and to confirm this data sheet is current please contact our Technical Service Department.



**DOWNLOAD THE RAG® FOR THE LATEST ADHESIVE RECOMMENDATIONS**

## F. Ball and Co. Ltd.

Churnetside Business Park,  
Station Road, Cheddleton,  
Leek, Staffordshire.  
ST13 7RS UK  
Tel: +44 (0) 1538 361633  
[www.f-ball.com](http://www.f-ball.com)  
[mail@f-ball.co.uk](mailto:mail@f-ball.co.uk)